



CODES 4000T 'Getting Started'

TES 1475D

Crypton Technology Business Park, Bristol Road, Bridgwater, Somerset TA6 4BX
Tel: +44 (0)1278 436200 Fax: +44 (0)1278 450567 Email: sales@cryptontechnology.com
www.cryptontechnology.com


Crypton Limited is registered in England and Wales at Hopton Industrial Estate, London Road, Devizes, Wiltshire. SN10 2EU. Company No. 3451389





Connecting the power supply


The laptop has its own internal battery so does not need the power supply connected for normal use. To charge the battery the power supply must be connected to the round socket located on the left hand side towards the rear of the laptop. The socket is marked with the following symbol:




Please refer to the Laptop user guide for further information and charging instructions.

Connecting the Scope (option)

The oscilloscope should be connected as shown right and then connected to the laptop using the USB lead into one of the USB connectors. The USB connectors are located on the left side of the laptop and identified by the symbol shown below.



If you do not wish to use the scope it can be left disconnected from the laptop.



Starting the Laptop

The Laptop is started using the power switch on the front on the laptop, which can be identified by the following symbol:



If the laptop doesn't switch on when you press the button, the battery may be flat. Please connect the power supply and try again.



The desktop Icons

The following icons are found on the desktop of the laptop:



Codex - This launches the Codex On Board Diagnostic program. Please refer to the CODEs user guide for further information on using this program.



CODEx Data - This launches the Codex workshop information program.



Toolbox - This launches the Toolbox program. Please refer to the Toolbox user guide for further information on using this program.

Codex Workshop Data

LICENCES

Gaining Authorisation for Codex and Workshop Data

Your purchase includes a free subscription period but before you can fully utilise CODEx and the Workshop data you need to obtain an authorisation code. Start the workshop data program by double clicking the CODEx Data icon. Click on the Program Settings icon in the top left hand of the screen and then select "License" on the left, then click on the "Activation" tab.



Info 2000



Program Settings

The window show below will appear. Choose whether you want to order by phone or fax and then click on "Proceed". Follow the on screen instructions.

Fax: 01278 450567

Tel: 01278 436226

On receipt of your site key enter the number into the site key box of the authorisation tab and click 'Ok'. Close Codex Workshop Data and restart the laptop. To complete the licence procedure run Codex workshop data by double clicking the CODEx Data icon. Once loaded close Codex workshop data and run Codex by double clicking the Codex icon.


The screenshot shows the 'Program Settings' window with the 'Activation' tab selected. The window title is 'Program Settings'. On the left is a 'Program Settings' sidebar with a tree view containing: User information, Regional Settings, Financial Settings, Licence (selected), Licence Transfer, and About. The main area has tabs for 'Licence Details', 'Activation', 'Advanced', and 'Floating Licence Snap Shot'. The 'Activation' tab contains the following text: 'Licence activation', 'To activate this product you need a licence. You can order a licence by sending the Site Code to your reseller. You will in return receive a Site Key. Enter the Site Key and click on "Apply".', a 'Site Code' field with the value '2F99 5F4E 8D19 37D7 8E5B' and a 'Copy Site Code' button, a 'Site Key' field with the placeholder 'Enter new site key' and an 'Apply' button, a 'Message' box with the text '[0]: Licence initialisation was successful' and '[-4]: The program has never been authorised at the current site', and an 'Order a licence (Site Key)' section with two radio buttons: 'Order licence by Phone' (unselected) and 'Order licence by Fax or by mail' (selected), and a 'Proceed' button.

This process will need to be repeated annually but will be free during your included subscription period.



External CD/DVD drive

In order to install updates to existing software or to install new software the supplied external CD/DVD drive must be connected to the laptop. The drive is connected by means of a USB port located on the side of the laptop. The port is marked with the symbol shown here.



For further information refer to the CD/DVD user guide. This is only required for installing updates and does not need to be connected normally.

Box Contents

The two large boxes contain all of the necessary leads etc to use the CODES 4000T product.

One of the boxes contains a set of vehicle communication leads required to communicate with the majority of vehicles currently covered by the CODES 4000T product. The second box contains the scope kit (optional), the EOBD and DMM units, a set of test probes and the amps clamp for the DMM, the flight recorder capture button and personality adapters for the vehicle communications leads.

